Siemens S7-1200

CPU 1212C AC/DC/Relay

Move, Compare and Math Operators Application

Objective

Monitor & control the level of water in tank

WWW.Codeando

- Compare: >,<, ==, In_Range
- MOV
- MUL



Code and CompileLearning Made Easy


www.codeandcompile.com

Software Platform by:









Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:

www.nfiautomation.org

Objective: Monitor & control the level of water in tank







The tank has been configured with **Analog mode.**



Objective: Monitor & control the level of water in tank

Assigned Inputs & Outputs:

PLC used **S7-1200**

Host: 192.168.0.1 Outputs 10.0 Q0.0 Filling Ind. Draining 10.1 Q0.1 Draining Ind. Stop **Emergency Stop** 10.2 Q0.2 Stop Tank 1 (Fill Valve) Tank 1 (Level Meter) ID100 (REAL) (REAL) QD100 (REAL) QD104 Tank 1 (Discharge Valve) ID104 (DINT) QD108 Liquid Level in % ID108 Analog Input

Programming Software Siemens TIA

3D Software Platform **FACTORY I/O**

Order FACTORY I/O Student license at:

www.nfiautomation.org

Steps to follow:

1. Use Drain Button 10.0 to control Drain valve QD104

- 2. Monitor the tank level **ID100** and control fill valve **QD100** in step mode
- 3. Indicate filling and draining operation with blinking of indicator **Q0.0** and **Q0.1** respectively
- 4. Display the tank level **ID100** in % on Liquid Level display **QD108**
- 5. Include emergency button 10.2 to halt the operation
- 6. Download the Logic and Test!

Analog **Outputs**



Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:

www.nfiautomation.org

Objective: Monitor & control the level of water in tank


Necessary Steps:


1. Define **tags** in Siemens TIA



2. Configure the tank to **Analog Mode**: \checkmark

Right Click on Tank -> Configuration -> Digital





PLC used **S7-1200** -

Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:


www.nfiautomation.org

Objective: Monitor & control the level of water in tank

How Analog Input and Output works in FACORY I/O:

Analog Input Analog Output







	L	Input Dec	Fill Valve	Discharge Valve, QD104
	-	0.0	Closed	Closed 🗸
		2.5	25% Open	2 <u>5% Open</u>
		5.0	<u>50% Op</u> en	<u>50% Ope</u> n
		7.5	75% Open	75% Open
		10.0	100% Open	10 <u>0%</u> Open



Programming Software
Siemens TIA

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:

www.nfiautomation.org

Objective: Monitor & control the level of water in tank

Steps to follow:


1. Use Drain Button 10.0 to control Drain valve QD104



Discharge Valve

Proportional Control





PLC used **S7-1200** •

Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:


www.nfiautomation.org

Objective: Monitor & control the level of water in tank


Steps to follow:


2. Monitor the tank level **ID100** and control fill valve **QD100** in step mode





Analog Input & Output Relation





PLC used **S7-1200** -

Programming Software
Siemens TIA

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:

www.nfiautomation.org

Objective: Monitor & control the level of water in tank


Steps to follow:

3. Indicate filling and draining operation with blinking of indicator **Q0.0** and **Q0.1** respectively









Objective: Monitor & control the level of water in tank

Liquid Level in %

Steps to follow:

Comment

4. Display the tank level **ID100** in % on Liquid Level display **QD108**

Network 4: Display the tank level ID100 in % on Liquid Level display QD108

MUL Real


PLC used V CO Tank Level IN1 Copies Out Display


Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**

Order FACTORY I/O Student license at:

www.nfiautomation.org





Programming Software **Siemens TIA**

3D Software Platform **FACTORY I/O**


Order FACTORY I/O Student license at:

www.nfiautomation.org

Objective: Monitor & control the level of water in tank

Steps to follow:

5. Include emergency button I0.2 to halt the operation



6. Download the Logic and Test!



You can control the **FACTORY I/O** environment without using hardware PLC via Control I/O Driver. This driver is available at NFI website <u>www.nfiautomation.org</u>. Special offer for student license.

Siemens S7-1200

CPU 1212C AC/DC/Relay

Move, Compare and Math Operators

Application

Thank yed eand condition of this presentation

and PLC code in the course!



Software Platform by:



